HITECH®
User's Manual Guide
G25
PROUD
enterlife

HITECH®

# User Manual of

# HITECH G25

Thank you for purchasing Hitech G 25. For best performance, we recommend you to go through the manual carefully.

## INDEX


MESSAGE ..... 3
CALL LOGS ..... 4
CONTACTS ..... 5
MY FILES ..... 5
MULTIMEDIA ..... 6
AUDIO ..... 7
CALENDAR ..... 7
GAMES ..... 7
TOOLS ..... 7
PROFILES ..... 8
SETTINGS ..... 9
INTERNET ..... 10
SPECIFIC ABSORPTION RATE ..... 11




## Message

The Messaging function is a network service. Sending and receiving Text/MMS can only be used if the service is proposed by your network operator.

You can send ordinary Text messages, enhanced Text messages (Text messages containing pictures, ring tones and animation as attachments, EMS for short). The SMS is sent to the Text messages center in the network firstly, and then to the target user. If the receiver's mobile is power off or cannot receive messages, the network will store the message temporarily and the store duration is determined by the user configuration and the service provider. I

The message will be directly stored in the SIM card if the capacity is not full. A blinking icon at the head row of the main screen will be displayed if the capacity is full. Messages unread

If the Text message has been sent to the receiver, a beep will sound. (If the tone for Text messages and message report are activated).

**[Write message]**

**[New SMS]**

- Send: Enter the appropriate number of the recipient or from the phonebook add
- Insert template: to the content of the message currently being edited into the common language
- Add contact info: Insert the contact person
- Add phiz: emoticons into the meaning of the representative
- Save as draft: will save the information to Drafts
- Exit: Exit message

**[New MMS]**

- Send: send MMS to the receiver
- Preview: Preview edited MMS content.
- Add new recipients: Enter the recipient's phone number or e-mail or group
- Add: add video/audio/picture to MMS
- Delete: Delete the message
- Save as draft: save as draft
- Set slide time(1s—600s): set the slide time of MMS
- Text layout: move the text above or down

**[Inbox]:**

- Reply: reply to SMS to each other.
- Delete: Delete short message

- Call: choose a voice call or a call to the sender IP calls
- Lock: lock cannot be deleted
- Move: Move the message to SIM or phone
- Copy: Copy the message to SIM or phone
- Mark: single marker or markers in whole or in text messages stored in SIM1/SIM2, mark or unmark after delete records
- Sort: In accordance with time / contact / theme / message type sort
- Delete repeated number: choose to delete the same number of records.
- Add to blacklist: Add the sender to blacklist

**[Outbox]**: Reading or processing stored in the Outbox of the SIM card message.
**[Drafts]**: Reading or processing stored in the Drafts of the SIM card message
**[Sentbox]:** read and process the mail stored in the SIM card has been sent information
**[Security inbox]** View the message which is locked
**[Templates]:** Use the function of templates
**[Broadcast message]:** Use the function of broadcast message
**[Voice mail server]:** use the function of voice mail server

## Call logs

You can view your recent call situation.
**[Missed calls]:** Show all missed calls list, select a view after a missed call occurred the date and time, phone number and times.
**[Dialed calls]**: Show all dialed calls list, select a view after a dialed calls occurred in the date and time, phone number and times.
**[Received calls]:** Show all answered the phone list, select a view after a phone that has the date and time of occurrence, telephone number, frequency,
**[Rejected calls]** Show all refused to answer the phone list, select a view after a missed call occurred the date and time, phone number and times.
Press the OK softkey to enter the options menu can be more than the number of call records in the following:

- Details: View the current record date, time, type.
- Call: Call the current number.
- Save: You can save the current record to the phone or SIM card
- Write message: send the current record of SMS.
- Add to contacts: the number of the record the name added to the existing record which
- Add to blacklist: the current record to reject a call which



- Delete: Delete the currently selected record
- Delete all: Delete all call records
- Mark: Mark to operation

**[Delete all]:** Delete all call records
**[Call times]:** Last time zero starting time for last call statistics, a total of dialed calls, received calls, all calls total, all the time can also be zero.
**[GPRS counter]**: Display the SIM card GPRS data.

## Contacts

You have 2 phonebooks in this mobile phone: SIM card and the mobile. The mobile can store 300 phone numbers and the SIM card's capacity depends on its type.
I In standby mode, enter a number, press the call key pieces to make a call, press the OK key to save

- If 'To SIM 1/2' is selected, users can edit name and number.
- If 'To phone' is selected, the user can edit the name, mobile number, image, ringtone, caller groups

Into the phone book list, the list on the left displays a small icon indicates that the record exists SIM card or mobile phone, the right is the record of the name and number information.
Standby mode, press the right soft key to enter into the address book or from the menu
Into the address book, do the following:
**[View contact]**:view the contact
**[Edit]:**edit current the contact
**[New]:** Create a record to phone or SIM
**[Delete multiple]:** Choose one or more records to delete
**[Import/Export]:** Copy/Import/Export records to T-Card or phone
**[Others]**
[Memory status]: Query the current SIM card and mobile phone storage capacity.

## My files

**[MemoryCard]:** SD card needs to support T card
[New folder]: Create a new folder.
[Delete]: delete the specified folder.
[Details] View the folder or file for more information
[Edit] the selected folder or rename the file or copy
[Search] Enter the folder name to find out.

[Sort] By the way you choose to sort the files.
[Mark] Select Mark / Unmark single / all
[More]

- Memory Card capacity: View the memory card capacity
- Format MemoryCard: Format memory card

## Multimedia

**[Camera]**

The phone supports photo, so you can capture your favorite scenes anywhere. Photos will be saved in the phone comes with a file system, photographs as JPG format, you can phone provides photographs sent to a computer via USB connection to view, can also be set Image for the standby

Note: This function can work without driver under Windows XP by directly connecting your mobile to the computer

**[Video Recorder]**

Set the parameter of DV and then use the function

**[Image]**

View the image which in phone memory or T-card

**[Video]**

Use the function of video player

**[FM radio]**

**[Auto search and save]:** Channel auto search and save
**[Channel list]:** View channel list
**[Save]:** Save the channel to the channel list
**[Manual search]:** Manually enter the channel and find
**[Open speaker]** Choose whether to open the microphone
**[background play]** Choose whether to open the Background Play
**[Record]:** Record the FM
**[Timing record]:** Set the time to record
**[Record file list]** The list of FM record file
**[Storage]** Set the location of storage
**[Help]:** FM Help

**[Recorder]**

[Start recording]: Start recording
[Record file list]: The memory card inside the recording file list
[Storage]: Set the locate of storage
[File format]: Set the format of record file



## Audio

Play audio files, MP3 songs; to play audio files, MP3 songs, press the Up and Down keys to adjust the volume, press the left and right keys to select the present, the next song, press the OK button for the on / off Music
[Music list]: Into playlist interface. Can be added to the play list editing and other operations
[Add]: Add songs or music playlist bookmark
[Set as ringtone]: The song is set to call or alarm tone
[Repeat]: Choose one/all repeat
[Shuffle]: Choose shuffle to play the music
[Settings]:

- Equalizer: Choose a variety of equalizer effects
- BT stereo output: Set the BT output
- BT stereo headset: Set the BT headset

[Open review]: Open the function of review
[Exit]: Exit menu audio player

## Calendar

Press the left soft key to access the calendar display interface, the first line shows the year, month, and the third line shows the week, the middle section shows the specific date of a month, the last line shows the right and left soft key in the message. Interface in the calendar, press the arrow keys on the date forward one week, press the arrow keys to move one week after the date, press the left arrow key date forward one day, press the right arrow keys to move the day after the date, select the date to a dark display
[Add new schedule]: a new agenda
[View schedule]: View the schedule one day save
[All schedule]: View the schedule all day
[Clear tasks today]: Clear the calendar day
[Clear all]: Empty all the schedules
[Go to date]: Enter the dates you want to find, the cursor will jump to that date quickly
[Weekly]: the week / month display calendar.

## Games

Provide two interesting game

## Tools

**[Alarm]**

This machine has three alarm times available for your settings. Access any time, you can set its status to on / off, ring time, repeat mode, ring tones, alarm clock name, etc.

**[Calculator]**
Can be continuously mixed arithmetic, the operation is simple, practical, convenient
**[Ebook]**
View the "txt" document
**[STK]**
Full name of the SIM card application toolkit (SIM Application Toolkit). It can provide you with flexible information functions, such as stock information, traffic information, weather and so on. STK functionality provided by the network operator decision. The business needs the support of SIM cards and network
**[World clock]**
View the time of countries
**[Bluetooth]**
[Open Bluetooth]: Choose to activate the Bluetooth
[Bluetooth visibility]:Bluetooth visibility set
[Paired device]; Search and paired Bluetooth devices
[Device name]; Local Bluetooth name
[Bluetooth file storage]; Storage location
[Help]: Help Documentation
**[Torch]**
Choose to open the torch

## Profiles

**[Add]**: Add the new profile
**[Delete]**: Delete the profile
**[Settings]**: set the selected mode
[Rename]: Rename the profile
[Ring settings]
- SIM call ring: set the SIM card of the ringing tone
- SIM message ring: set the SIM card message tone

[Adjust volume]
- Caller ringtone: set the ringing tone volume
- Message ringtone: ring volume settings information
- Call volume: Set the volume of calls
- Alarm & calendar volume; set the alarm tone
- Power ringtone: the voice of setting switch

[Ring type]
- Call alert: a ring, vibration, silent, vibration and ringing and ringing after the first five vibration incoming call alert for you to choose
- Message alert: a ring, vibration, silent, ringing and message alert vibration four ways for you to choose
- Alarm & calendar remind: a ring, vibration, silent, ringing and message alert vibration four ways for you to choose



[Other alert rings]
- Key tone: set the key tone of voice
- Battery low alert: Choose open the alert of battery low
- Power ringtone: Set the sound is turned Off
- Dial tone: Activate dial tone

## Settings

**【Call setting】**
**[Dual-SIM]**
[Standby mode]: Dual SIM standby or standby only SIM1 or SIM2 only
[Reply by original SIM]: Reply the call/SMS by original SIM
[Set SIM name] SIM1 and SIM2 in the card slot to set the display name
**[Call divert]**: transfer a call, respectively SIM1/SIM2
- Call forwarding unconditional: Set a forwarding number, for forwarding all calls are
- Call forwarding on busy: set the forwarding number, transfer calls when in busy
- Call forwarding on no reply: Set a forwarding number, in case of no response transfer
- Diver if unreachable: to set the forwarding number in the phone unable to connect the case of transfer
- Cancel all diverts: cancel all of the transfer

**[Call waiting]** open call waiting, respectively SIM1/SIM2
**[Call barred** respectively SIM1/SIM2 call for restrictions
**[Hide ID]** respectively SIM1/SIM2 to hide the machine when the power numbers.
*** SIM card, operators need to support**
**[Others]**
[Call time minute reminder] Select the open or closed during a voice call has prompted
[Auto redial] Select whether to open automatically redial function
[Reply SMS after reject] Select whether to reject messages or return after any key answer
[Auto record voice call] Auto record the voice call
**【Phone settings】**
[Date & time]
- Set time: set the phone to display the time
- Set date: set the phone to display the date
- Time format: Set the display time format
- Date format:Set the date display format
- Update time settings: Select open update time

[Language settings] Select phone display language.
[Shortcut settings] Set the shortcut
[Auto power on/off] Set the time and frequency of Automatic Turning
[Power management] check the battery's current charge
[Restore factory settings] restore the factory settings
**【Display】**

[**Animation effect**]: Set the power on/off animation
[**Wallpaper settings**] Set wallpaper
[**Idle display setting**] Set the idle
[**Contrast**] adjust the screen's backlight brightness
[**Keypad backlight time**] Set the backlight time key
[**Auto keypad lock**] Set the auto keypad lock
【**Security**】
[**PIN**] Select open or modify the phone's PIN code
[**Modify PIN2**] PIN2 choose to modify the phone code
[**Phone locked**]: Set the phone locked
[**Modify the cellphone password**]: Modify the password of phone
[**Privacy**] set access to enter the password to view functionality. (Including: call logs / message / camera / phonebook / my files / ebook / calendar / U disk/audio player/video player)
[**Lock screen by end-key**] press the end key to select whether the off-screen function
[**Guardlock**] to set the security password and open the feature, open the opportunity for the card and then prompts for security password, if the wrong password is entered three times, the phone can receive within 24 hours of alarm information
[**Fixed dialing**] Set the fixed dialing function
[**Blacklist**] Set the blacklist
【**Connections**】
[**Network account**]: Create or edit the network account
[New connection] Create a new Internet account
[Add from list] from the system built-in Internet account to add a new account
[Search] from the current logged on to Internet search to the card account information, which added to the list after the selected
[Delete]: delete the selected account
[Edit]: edit the currently selected account
[**GPRS service**]: Choose open or close GPRS service
[**Data connection settings**]: The type of data connection
[**Network selection**]: Choose auto or manual select network
Use the effect for menu list

## Internet

Use the function of internet
[**Bookmark**] Website of interest can be saved in the bookmarks and the bookmarks can be edited or direct them to surf.
[**History**] Mobile recently logged in the menu page is saved, you can directly select the records inside the surf
[**Offline pages**] Throughout the course of mobile browsing, save the snapshot shown here
[**Homepage**] Open the home page
[**Settings**] Set account/homepage/content/restore default



[**Exit**] Exit browser
[**Yahoo**] connect to yahoo
[**FaceBook**] Connect to FB
[**Twitter**] connect to twitter

## Specific Absorption Rate

Mobile device is a radio transmitter and receiver. It is designed to not exceed the limits for exposure to radio waves recommended by various governments. In India, these guidelines were developed by the Government of India, Department of Telecommunications, Ministry of Communications and IT and include safety margins design to assure the protection of all persons, regardless of age and health, and to account for any variations in measurements.
The guidelines use a unit of measurement known as the Specific Absorption Rate (SAR).
SAR level for mobile handsets Shall be limited to 1.6 Watt/kg, averaged over a 6 minutes period and taken over a volume containing a mass of 1 gram of Human tissue OR 2.0 W/Kg averaged over 10 gram tissue

Highest SAR Value for G25 as below-

When tested on head -0.404Watt/Kg
When tested on body -0.432Watt/Kg

## Important Notice

**COPYRIGHT NOTICE**

*Copyright © 2013, Hitech Cellphones Pvt. Ltd. all rights reserved.*

**TRADEMARKS**

Hitech Cellphones Pvt. Ltd. and Hitech logos are trademarks or registered trademarks of Hitech Corporation. Other companies and product names mentioned herein may be trademarks or trade names of their respective owners, and the mention is subject to compulsory citation purpose.

**WARRANTY DISCLAIMER**

Hitech Cellphones Pvt. Ltd. makes no representations or warranties, either expressed or implied, by or with respect to anything in this document, and shall not be liable for any

implied warranties of merchantability or fitness for a particular purpose or for any indirect, special or consequential damages.

**CONFIDENTIALITY STATEMENT**

The contents of this document (including any accessory) are confidential. The receiver should be aware of the confidentiality of the document and will neither use it for any other purpose except for the purposes specified nor disclose the document to any third party.

HITECH

HITECH®

For all product related complaints/assistance please contact:
The Care Manager, HITECH CELLPHONE PVT. LTD.,
Fancy Plaza, 4th Floor, 2 Dent Mission Rd., Kol-700 023
Toll Free No.: 1800-345-5822/1800-200-3969
Visit us at: www.hitech-mobiles.com
Customer Care e-mail ID: care@hitech-mobiles.com

HITECH®

For all product related complaints/assistance please contact:
The Care Manager, HITECH CELLPHONE PVT. LTD.,
Fancy Plaza, 4th Floor, 2 Dent Mission Rd., Kol-700 023
Toll Free No.: 1800-345-5822/1800-200-3969
Visit us at: www.hitech-mobiles.com
Customer Care e-mail ID: care@hitech-mobiles.com

HITECH®

User's Manual Guide

G25
PROUD

enterlife